



















Assembly Instruction Sheet

CAUTION: Because of the edges of some parts before assembly may be sharp, please handle unassembled parts carefully.



partslist	Qty
A 	1PC
B 	1PC
C 	1PC
D 	5PCS
E 	1PC
F 	1PC
G M6*30mm 	4PCS
H M8*20mm 	3PCS
I M8*ø17 	7PCS
J M8*ø14 	3PCS
K M6 	1PC
L 	1PC



Never wave or bump the chair fiercely.
 Never wipe with damp cloth or hard things.
 Stock in door after cleaning when not used.

sømcasa